

e-SV Series shaft seal replacement

How long does it actually take?

1. Remove coupling guard (four screws)	60 seconds
2. Remove coupling (four bolts)	130 seconds
3. Remove seal gland screws (four bolts)	120 seconds
4. Remove seal gland	20 seconds
5. Remove rotating portion of seal from inside pump	20 seconds
6. Remove stationary portion from the seal gland	20 seconds
7. Inspect seal	60 seconds
8. Replace rotating portion of seal on pump shaft	20 seconds
9. Replace stationary portion of seal into seal gland	40 seconds
10. Replace seal gland o-ring	20 seconds
11. Install seal gland on pump	20 seconds
12. Tighten bolts on seal gland	110 seconds
13. Replace coupling / coupling bolts	110 seconds
14. Set rotating stack height with shim	30 seconds
15. Tighten coupling bolts	70 seconds
16. Rotate shaft to check for rub	20 seconds
17. Replace coupling guard and screws	30 seconds

Total 15 minutes

Xylem Inc.
2881 East Bayard Street Ext.,
Suite A
Seneca Falls, NY 13148

Phone: (866) 325-4210
Fax: (888) 322-5877
xylem.com/goulds

Learn more about
the e-SV Series
product line



This information is subject to change without notice. All information presented herein is believed reliable and in accordance with accepted engineering practices. Xylem makes no warranties as to the completeness of this information. Users are responsible for evaluating individual product suitability for specific applications. Xylem assumes no liability whatsoever for any special, indirect or consequential damages arising from the sale, resale or misuse of its products.

© 2026 Xylem Inc. or its affiliate. All rights reserved. Xylem is a registered trademark of Xylem Inc. or one of its subsidiaries. Goulds Water Technology is a registered trademark of ITT Manufacturing Enterprises LLC and is used under license. All other trademarks or registered trademarks are the property of their respective owners.